

**Installation Instructions
Knurled Knob Accessory Set (SET-CL-KNOB)
for SKYLOTEC CLAW (CL-001)**

The following instructions are for the installation of the Knurled Knob Accessory Set (SET-CL-KNOB) for retrofit to the SKYLOTEC CLAW (CL-001). This is an accessory designed for ease of use when installing and removing the CLAW from the vertical wire rope climbing system.

SET-CL-KNOB contents:

The SET-CL-KNOB accessory kit includes a knurled knob, an installed set screw with dry lock patch and a hex key wrench (Figure 1).

Installation:

1. Locate the CLAW Release Pin on the side of the CLAW.
2. Slide the Knurled Knob onto the Release Pin of the Claw (CL-001). Make sure the threaded hole with set screw faces the flat side of the Release Pin, and the Knurled Knob sits flush with the surface of the Claw. Tapping and wiggling the knob onto the pin may be necessary.
3. Tighten the set screw as much as possible with the Hex L-key. The set screw will be flush with the surface of the Knurled Knob and will secure the Knob onto the Release Button. Once secured, the Knob will lock into place due to the dry lock that is present on the set screw.
4. Test that the Knob is fully attached by pulling up on the Release Button. Release the Knob and verify the Knob returns to the closed position and the Knob sits flush with the surface of the Claw.

Figure 1



**Step 1
Release Pin**

Step 2



Step 3



Step 4

